



Rear Derailleur



System Battery Check

Press the **function button** on the **rear derailleur** for **0.5s** or less.

The LED will then indicate the battery charge level.



bettershifting.com/battery

100% - 51%



Solid green (3 seconds)

50% - 26%



Flashing green (8 times)


25% - 1%



Solid red (3 seconds)

Shifter Battery Check


Press **both** buttons on a single shifter for **0.5s**. The shifter LED will indicate the battery level.



100% - 11% Yellow/green

10% - 1% Red

0% Off



bettershifting.com/battery


Synchronized Shift

To change to the next shift mode, press the **function button** twice.

Shift Mode 1 is usually set to **Semi Synchronized** shift, while the default for **Shift Mode 2** is **Full Synchronized** shift.




bettershifting.com/shiftmode



Adjustment mode

Press the **function button** for **2-5 seconds** to enter **derailleur adjustment mode**.



The **Y-button** moves the derailleur **away** from the frame.

The **X-button** moves the derailleur **towards** the frame.



bettershifting.com/adjustment


Visit the adjustment page for info on how to adjust the front derailleur.

When done, press the **function button** for **0.5s** to exit **adjustment mode**.

Bluetooth Connection Mode

Press the **function button** for **0.5-2 seconds** to trigger **Bluetooth Connection Mode**.

The LED will flash while the bike is in **Bluetooth Connection Mode** (30 seconds).



bettershifting.com/bluetooth